



STORMWATER INLET REMOVAL AND INSTALLATION NOTES

- 1) WHERE INLETS ARE TO BE REMOVED, CONTRACTOR MUST COORDINATE WITH MUB AND OWNER ON TECHNIQUES AND PROCEDURES FOR ABANDONMENT AND CAPPING OF ASSOCIATED LATERAL.
- 2) WHERE INLETS ARE TO BE INSTALLED, CONTRACTOR MAY USE A COMBINATION OF PRECAST AND CAST-IN PLACE ELEMENTS TO THE SPECIFICATIONS LISTED IN THE BID DOCUMENTS. INLETS MUST BE SET AT A GRADE SATISFACTORY TO MUB AND OWNER INSPECTORS.
- 3) WHERE INLETS ARE TO BE MAINTAINED AROUND NEW SIDEWALK, CONTRACTOR MUST MAINTAIN INTEGRITY OF INLET AND RAISE LID/ADD RISERS AS NECESSARY AND SPECIFIED BY MUB.